


BTSPS MON 1 200/60C5U

**Technical Manual
Power supply**

Version 00

BRUKER



The information in this manual may be altered without notice.

BRUKER accepts no responsibility for actions taken as a result of use of this manual. BRUKER accepts no liability for any mistakes contained in the manual, leading to coincidental damage, whether during installation or operation of the instrument. Unauthorised reproduction of manual contents, without written permission from the publishers, or translation into another language, either in full or in part, is forbidden.

This manual describes the units as they are at the time of printing. On request, the manufacturer shall supply circuit diagrams, lists of components, descriptions, calibrating instructions and any other information for use by qualified personnel of the user, in charge of repairing the parts of the unit which have been stated by the manufacturer to be "repairable". Such supply shall in no event constitute permission to modify or repair the units or approval of the same.

All rights reserved for the units, circuits, processes and appellations mentioned herein.

This unit is not designed for any type of use which is not specifically described in this manual. Such use may be hazardous.

BRUKER BIOSPIN

June 2004

Wissembourg, France

Unit P/N W1213137

Manual P/N : W1213142

Contents

	Contents	5
	Index	7
1	Generalities	9
1.1	Power supply identification	9
1.2	Output specifications	9
1.3	Input specifications	10
1.4	Stability $\Delta I/I$ at I Max	11
1.5	Technical contact	12
2	General installation instructions	13
3	Safety instructions	15
4	Maintenance	17
5	Wiring diagrams	19
5.1	BPS Cabinet wiring diagram WS125698A	20
5.2	BEC-1 Local control unit wiring diagram WS125413A	21
6	B-EC1 Main board	23
6.1	WS125467A	24
	CPU, Interface Bus	25
	Display	26
	Relays	27
	Status inputs	28
	DAC and 10V Reference	29
	EEPROM+DAC	30
	ADC12+5V Reference	31
	ADC SigmaDelta	32
	Regulation	33
	Voltage booster	34
	Aux.power supplies	35
	EMC	36
7	BEC-1 Display Board	37
7.1	N3-3S1996	38
	Layout display B-EC1	39

8	<i>BMC-20 CPU Interface board 2XRS IEEE</i>	41
8.1	N3-3S2226	42
	2Xrs232, IEEE	43
	Jumper config.IEEE, RS232C	44
	PAL 22V10	45
	PAL 16V8	46
	PAL 22V10	47
	PAL 22V10	48
9	<i>Power stage</i>	49
9.1	WS123887	50
10	<i>SEM Thyristor controller</i>	51
10.1	WS125402A	52
11	<i>Shunt amplifier</i>	53
11.1	WS122662A	54
12	<i>Divider U/BH15 Adjusment</i>	55
12.1	WS121906A	56
13	<i>Board aux power supply</i>	57
13.1	WS125239A	58
14	<i>ZERO CROSSING KIT UNIVERSEL</i>	59
14.1	Zero crossing module wiring diagram WS123931	60
14.2	BMN zero crossing ER 500mA wiring diagram WS23361 ...	61
15	<i>Warranty</i>	63

Index

Generalities

1

Power supply identification

1.1

UNIT/TYPE	BTSPS MON 1 200/60C5U	DATE	16/06/2004
SERIAL N°	W1213137	TESTED BY	A. KREISS
CUSTOMER	UNI LEUVEN BELGIQUE	SIGNATURE	

Output specifications

1.2

CHANNEL	OUTPUT VOLTAGE	OUTPUT CURRENT	OUTPUT POWER	LOAD RESISTANCE
1	200V	60A	12KW	3.33ohm

Power line

Type :

- Mono phase
- Three phase X
- With neutral
- Without neutral X

Voltage..... 400 V

Line fuses/protection..... 40 A

Nominal power 17 KVA

Auxiliary line

Voltage..... V

Current..... A

Cooling mode

- Water X
- Air X

Max input pressure 10 Bars

Water circuit tested at 16 Bars/1H

Minimum flow rate..... 2 l/mn

Requested delta pressure in/out..... 1.5 Bars

Max water input temperature 30°C

Ambiant air

Max temperature 30°C

Stability $\Delta I/I$ at I Max

1.4

Stability $\Delta I/I$ at I max

Warmup time = 30mn

DC to 10Hz..... per mn $1 \cdot 10^{-5}$

DC to 10Hz..... per 8 hours $5 \cdot 10^{-5}$

Temperature coef

Shunt..... +/-5 ppm/°C

Regulation 10 ppm/°C

Cabinet

- Dimensions
 - Height 1345 mm
 - Lenght..... 600 mm
 - Depth 600 mm
- Weight 199 kg

BRUKER BIOSPIN

Power Electronik Department

34, Rue de l'industrie

67166 WISSEMBOURG CEDEX (FRANCE)

TEL : +33 (0)3 88 73 69 42

FAX : +33 (0)3 88 73 68 86

E-MAIL : power-elec.support@bruker.fr

General installation instructions

2

INSTALLATION - General instructions.

The installation of the device must be done only by an authorized and qualified technician, in total accordance with the running standards. Every breakdown due to a non-respect of the following instructions will not be attributable to Bruker and will not be covered by the guarantee clauses.

A) To offer an optimum ventilation:

- Respect a 20 cm minimum distance between the device and the walls.
- Do not seal the different air admissions.
- Do not cover air extractions.
- The non-respect of these instructions can lead to an over-heating of the device and deteriorations can be a result.

B) Connections:

- *Cooling circuit* (for water-cooled devices only): connect the cold water input to the 'Water IN' connector. Connect the warm water output to the 'Water OUT' connector. For water flow, pressure and quality please refer to the *Characteristics* chapter.
- *Mains input*: connect the mains input cable to the *Line IN* or *Mains* connector or terminals. In case of connection on terminals must the protective earth cable be connected to the foreseen and adequate terminal. Use the provided cables. The cables may not be provided for specific devices. In that case, types and sections of cables must be in accordance with the running standards. Too narrow a section can lead to an excessive heating or even fire. The type must be in accordance with the voltage of the equipment. Flash or electrocution risk !!! The upstream cable protection must also be in accordance with its section. Refer to the *Characteristics* chapter.
- *Outputs to the load*: connect the '+' cable of the load to *DC OUT+* terminal and the '-' cable of the load to *DC OUT-* terminal. Please respect the instructions of the previous paragraph.
- *Load interlock cables*: connect the cable of the load interlock circuit to *Sec.Ext* or *TB1* terminals. In case of device equipped with two interlock circuits, connect the first circuit to *ec.Ext1* or *TB1-1/2* terminals and the second one to *Sec.Ext2* or *TB1-3/4* terminals. The circuit must be closed in both cases to start the equipment. Don't never apply any voltage between these two terminals. The contact(s) of the load must be floating, open = default ($U \leq 15V$, $I \leq 20mA$).
- *Special cables*: please refer to the *Installation – Specific instructions* chapter.



Safety instructions

3

- This device is an electric generator (supply) and must be used for its especially designed applications only. Please refer to the *Star up/Running* and *Control module* description chapters.
- This latter contains live parts and running without his protection panels or doors opened is forbidden. Switching off imperatively the mains inputs before opening is obligatory. **Electrocution risk !** In certain types of device and depending the configuration, an electric potential can be generated between the analogue ground and the protective earth. Be sure of voltage absence before every intervention on the device.
- The different wirings must be done by an authorized and qualified technician. Use only the provided cables. For specific devices, cables may not be provided. In that case, types and sections of cables must be in accordance with the running standards. Too narrow a section can lead to an excessive heating or even fire. The type must be in accordance with the voltage of the equipment. **Risk of flash or electric shock !**
- For high voltage devices, please respect attentively indications, installation and start up instructions.
- Never disconnect any cable during the use of the device. Flash, burning and electrocution risk !
- Sprinkling or pouring liquids on the device is forbidden. Use a wet or alcohol soaked rag to clean the machine.
- For any maintenance operation, refer to the chapter *Maintenance*. The different operations must be done by an authorized and qualified technician or contact the Bruker's After Sales Service. Email: power-elec.support@bruker.fr
- Warning concerning the pacemakers: the device emits EM waves and the magnet produces a strong magnetic field that can disrupt the functioning of pacemakers.

Information:

- The model identification plate is placed at the upper front or rear side from the cabinet frame. This plate is placed at the rear side in case of rack modules.
- Symbols :



Maintenance

4

MAINTENANCE – LOW VOLTAGE DEVICE

Every intervention on the device must be carried out by an authorized and qualified person. Any failure due to a non-respect of the following instructions will not be attributable to Bruker and will not be covered by the guarantee clauses. Before any intervention, please read the safety instructions described under the heading *Safety Instructions*.

A) Points to check every three months:


- *Visual checking*: proceed to visual inspection of the device.
- *Water tightness of the cooling system*: check the absence of leak or drops at the connections level. Replace any defective tubing or connector.
- *Functionality of the water flow sensor*: stop the water inlet and check that *Water Error* is displayed. If the default is not detected, check or replace the flow meter.
- *Functionality of the fans*: check the fans for easily and silently operating. Replace if necessary.
- *Functionality of the interlock systems*: check the different circuits and the corresponding error messages. Be sure of their efficiency.

B) Complementary checks to carry out every six months:

- *Cleaning out the components and the filters*. Any dust or mess must be removed by vacuum extraction or with a soft bristle brush. Clean the dust filters (only on certain types of devices) or replace if necessary. For any cleaning of components, please use a 90° alcohol impregnate rag. Don't never use water.
- *Checking hoses and cooling plates*: replace any defective, porous or harden component.
- *Power circuit*: check the tightness of screws and connectors of the power circuit. Replace components or cables which are altered by time or by an over-heating due to a misconnection.
- *Transistor power stage* (only on power supplies fitted with serial regulation): check the state of every emitter fuse. Any broken fuse must be replaced, the corresponding transistor as well. To dismantle the transistor, remove tin from the two pins with an unsolder pump and remove the two fixing screws from the case. Replace the transistor by the same type or equivalent. Keep in mind the drop of thermal paste under the middle of the transistor. Put back in place the two screws and solder the two pins.

Wiring diagrams


5



ART: W121338	EC: 00	DRAWN: DWE 03/04	VISA:
BPS ARMOLMON 1 200/60CSU		APPROV. DATE:	VISA:
DRAWING DIAGRAM		DWG: WS125698	A SHEET: 1 / 1



This document is proprietary to BRUKER BIOSPIN SA and may not be reproduced or disclosed in third parties without prior written permission.
Ce document est la Propriété Industrielle de la société BRUKER BIOSPIN SA et le présent doit être reproduit en version à jour sans autorisation écrite préalable.




REV	MODIFIED DATE	NUMBER	COMMENTS
ART : W1211454	EC :	DRAWN: SF	VISA :
		DATE: 02/01	
BPS LOCAL CTRL UNIT		APPROV:	VISA :
BIPOLAR BEC-1		DATE:	
RS232+IEEE		DWG : W2S125413	A SHEET : 1/1
WIRING DIAGRAM			



B-EC1 Main board


DWG : WS125467A



BRUKER

ART : W1211467
 EC :
 DRAWN: AKI 02/10/2001
 APPROV. DATE: VISA:
 DWG: WS12 9487
 SHEET: 1 / 13

B-EC1 MAIN BOARD BIP.
 Main
 PCB Number = W4P12 5371




ART : W1211467 **EC :**

B-EC1 MAIN BOARD BIP.
CPU BUS INTERFACE

DRAWN: AKL 02/10/2001 **VISA:**


APPROV: DATE: **VISA:**

DWG: W1215467 **A** **SHEET: 2 / 13**




BRUKER

ART: W1211467	EC:	DRAWN: AKL 02/10/2001	VISA:
B-EC1 MAIN BOARD BIP. DISPLAY INPUT/OUTPUT		APPROV: DATE:	VISA:
		DWG: W15P2.5467	A SHEET: 3 / 13




		ART: W1211467	EC:
		B-EC1 MAIN BOARD BIP. CONTROL RELAYS	
DRAWN: AKL 02/10/2001	VISA:	APPROV: DATE:	VISA:
DWG: W4S25467	A	SHEET: 4 / 13	



BRUKER


B-EC1 MAIN BOARD BIP. STATUS INPUTS


ART: W1211467	EC:	DRAWN: AKL 02/10/2001	VISA:
APPROV: DATE:		VISA:	
DWG: WMS12.5467	A	SHEET: 5 / 13	



BRUKER

ART: W121467	DRAWN: AKL 02/10/2001	VISA
B-EC1 MAIN BOARD BIP.		
MAIN DAC AND 10V REFERENCE		
EC:	APPROV. DATE:	VISA
	DATE: WAST25467	A
		SHEET: 6 / 13





ART : W1211467 EC :


BRUKER


DRAWN: AKI 02/10/2001 VISA:

APPROV: DATE: VISA:

DWG: W4S125467 A SHEET: 8 / 13


B-EC1 MAIN BOARD BIP.
12 BITS ADC AND 5V REFERENCE






BRUKER

ART: W121467	EC:	DRAWN: AKL 02/10/2001	VISA:
B-EC1 MAIN BOARD BIP.		APPROV: DATE:	VISA:
LOW DRIFT REGULATION		DWG: WMS12.5467	SHEET: 10 / 13






ART : W1211467		EC :	
DRAWN: AKL 02T102001		VISA:	
APPROV: DATE:		VISA:	
DWG: WAS125467		A	SHEET: 12 / 13



B-EC1 MAIN BOARD BIP.
AUXILIARY POWER SUPPLIES




ART: W121467		EC:	
B-EC1 MAIN BOARD BIP. EMC components			
DRAWN:	AKL 02/10/2001	VISA:	
APPROV:		VISA:	
DWG:	WMS125467	A	SHEET: 13 / 13



BEC-1 Display Board

7

DWG : N3-3S1996




BTSPS MON 1 200/60C5U Version EC00BRUKER

2 (65)

Part number	Serial number	
N	X	
	BRUKER Analytik	Print No : 9502
	Document Number: N3-3S1996/1	Name : SCHNELL
Size: A3	Title : DISPLAY B-EC1	
Date: 10-Feb-2000	Sheet: 1 of 2	Revision: 01

COTE COMPOSANT



COTE CUIVRE




Part Number
W1210708


	BRUKER Analytik	Print No : 9502
	Name : SCHNELL	
Document Number: N3-3S1996/2		
Size: A3	Title : Layout display B-EC1	
Date: 21-Mar-2000	Sheet: 2 of 2	Revision: 01

***BMC-20 CPU
Interface board 2XRS
IEEE***


8

DWG : N3-3S2226




Part number	Serial number	
N833	X	
	BRUKER Analytik	Print No : 8904
	Name : SCHNELL	
Document Number: N3-3S2226/1		
Size: A3	Title: CPU & IEEE 488, 2 x RS232C interface	
Date: 9-Mar-2000	Sheet: 1 of 7	Revision: 00

BTSPS MON 1 200/60C5U Version EC00BRUKER



Jumper configuration is shown on dedicated sheet 89043.SCH

	BRUKER Analytik	Print No : 8904
	Name : SCHNELL	
Document Number: N3-3S2226/2		
Size: A3	Title : 2 x RS232C, IEEE 488	
Date: 9-Mar-2000	Sheet: 2 of 7	Revision: 00





	J1	1 2 3	EPROM 2764 OR 27128
	J2	3 2 1	RAM MK48208B
	J3	3 2 1	RAM at +5V
	J6		Protective ground to GND
	J7		Watchdog enable


	J1	1 2 3	EPROM 27256
	J2	3 2 1	RAM 62256
	J3	3 2 1	Buffered RAM with external battery



	BRUKER Analytik	Print No : 8904
	Name : SCHNELL	
Document Number: N3-3S2226/3		
Size: A3	Title : Jumper config. IEEE 488, 2xRS232C	
Date: 9-Mar-2000	Sheet: 3 of 7	Revision: 00









pin: 1, 2, 4, 5, 13 not used

	BRUKER Analytik	Print No : 8904
		Name : SCHNELL
Document Number: N3-3S2226/6		
Size: A4	Title : PAL 22V10 or equ. bd 8904 IC5 vers A5	
Date: 9-Mar-2000	Sheet: 6 of 7	Revision: 00

pin 3, 5, 7, 11
13, 16, 17 | => not used




	BRUKER Analytik	Print No : 8904
	Name : SCHNELL	
Document Number: N3-3S2226/7		
Size: A4	Title : PAL22V10 or equ. bd 8904 IC11 vers F11	
Date: 9-Mar-2000	Sheet: 7 of 7	Revision: 00

Power stage

9


P/N : W1205493



***SEM Thyristor
controller***

10


DWG : WS125402A



Shunt amplifier

11


DWG : WS122662A




***Divider U/BH15
Adjustment***

12

DWG : WS121906A




A	22/06/94		CORRECTION C1 C2 C3	
REV	MODIFIED DATE	NUMBER	COMMENTS	
ART: W1201990		EC:	DRAWN: SF	VISA:
			DATE: 95/12	
BPS DIVIDER U / BH15 ADJUSTMENT			APPROV: PH	VISA:
			DATE: 95/12	
		DWG: W4S12 1906	A	SHEET: 1/1
		DSK 863		



***Board aux power
supply***

13

P/n : W1210421



BOX CONNECTION

BOX CONNECTION


REV	MODIFIED/DATE	NUMBER	COMMENTS														
<table border="1" style="width: 100%;"> <tr> <td>ART: WL210418</td> <td>EC:</td> <td>DRAWN: AKL</td> <td>VISA:</td> </tr> <tr> <td colspan="2" rowspan="2">BPS PWR5217 24V POWER SUPPLY</td> <td>DATE: 08/06/99</td> <td></td> </tr> <tr> <td>APPROV: DATE:</td> <td>VISA:</td> </tr> <tr> <td>DWG: WAS12 5239</td> <td>A</td> <td>SHEET: 1/1</td> <td></td> </tr> </table>				ART: WL210418	EC:	DRAWN: AKL	VISA:	BPS PWR5217 24V POWER SUPPLY		DATE: 08/06/99		APPROV: DATE:	VISA:	DWG: WAS12 5239	A	SHEET: 1/1	
ART: WL210418	EC:	DRAWN: AKL	VISA:														
BPS PWR5217 24V POWER SUPPLY		DATE: 08/06/99															
		APPROV: DATE:	VISA:														
DWG: WAS12 5239	A	SHEET: 1/1															




**ZERO CROSSING KIT
UNIVERSEL**

14

P/N : W1209207





WARRANTY Extracts of general conditions.

Unless otherwise specified on the offer/order documents, the warranty extends as follow:

- The warranty covers parts and labour.
- Handling and transport costs induced by a send back to Bruker from a device during the warranty period or costs related to a site servicing from an engineer are not covered and are in charge of the customer. During the warranty period, handling and transport costs from Bruker to the customer from a repaired device are in charge of Bruker.
- Contact the Bruker's After Sale Service before sending back a device.

Mail: power-elec.support@bruker.fr

Phone : +33 3 88 73 69 42

A repair number will be affected in order to make easier the follow up and to short the repair time.

- The warranty will only be applied in case of trouble which results from a normal and as specified running.
- The warranty doesn't cover troubles which result from a no respect of the installation, start up, running and safety instructions.
- Warranted period: 12 months starting from the site installation made by a Bruker engineer, or at maximum 18 months from the delivery date.

